

**6. AUTO DIMMING:** Mid, Off or Low (comes set at low)

Press **Menu** and then press the Up/Down buttons to access the Auto Dimming line.

Use the L/R arrows to scroll to the level you want

Press **Menu** to save the setting

Brightness dims at 7:00pm, brightens again at 7:00am

**7. COLOUR MODE:** White or Yellow

Press **Menu** and then press the Up/Down buttons to access the Colour mode line.

Use the L/ R arrows to scroll across to the colour you want

Press **Menu** to save the setting

**8. ALARM TIME:**

Press **Menu** and then press the Up/Down buttons to access the Alarm Time 1 line.

Press **OK** to select the field to be modified. A blue line will appear under the numbers.

Use the Up/down buttons to adjust the number

Use the L/ R arrows to scroll across to other numbers you want to change

Press **OK** to save the setting, Press **Menu** to exit settings

**9. ALARM 1 FREQUENCY:** Off / Once / Repeat /

Monday to Friday / Weekend

Press **Menu** and then press the Up/Down buttons to access the Alarm 1 frequency line.

Use the L/R arrows to scroll to the frequency you want

Press **Menu** to save the setting

**10. ALARM VOLUME:** Press **Menu** and then press the

Up/Down buttons to access: **Volume:** currently **8**

Use the Up/down buttons to adjust the number from 1-10.

Press **OK** to save the setting, Press **Menu** to exit settings

# Mindjig

www.mindjig.co.nz  
info@mindjig.co.nz  
09 600 3251

## DIGITAL DAY CLOCK

- Day of the week
- Time
- Time of Day
- Date
- Alarm
- Auto dimming



### SPECIFICATIONS:

**Dimensions:**

21.7 x 17.2 x 2.4 cm

**LED Size:** 160 x 120 mm


**Backlight:** LED

**Resolution:** 1024 x 768

**AC Power Adapter:**

Input 100 - 240V

**AC Output DC:** 5V - 1A



### WARNING:

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

**CAUTION do not remove back cover.**



## DAY CLOCK - Getting Started:

**1 Remove the clock and AC adaptor from the package.**

**2 Plug the input connector of the AC Adaptor into the 'DC in' hole on the back of the device.**

**3 Plug the clock into the wall and switch on.**

- In 5 seconds the clock will display. If the exact time, day and date don't appear to be correct try turning the clock off and on again. ***These settings can be manually set and will need to be changed for daylight savings*** - see information on following pages.
- ◇ **Always take care not to apply pressure to the screen.**
- The clock can be used on a secure flat surface, it has an adjustable bracket. For more stability make sure the bracket is extended, you need to push it down and around the catch at the back. Alternatively the clock can be mounted on the wall.
- ◇ **Ensure the clock has adequate ventilation and is away from direct heat sources.**
- See instructions for setting the alarm (and volume) on the back page. The alarm will ring for 60 seconds and then go off on its own, or you can manually stop it by pressing any button on the back of the clock.
- The clock will automatically dim to low from 7.00pm until 7.00am. You can turn this off if not wanted. See #6
- ◇ **Please do not attempt to plug anything into the USB port. This is used for the original clock setup only.**

[www.mindjig.co.nz](http://www.mindjig.co.nz) 09 600 3251 [info@mindjig.co.nz](mailto:info@mindjig.co.nz)

**1. SET TIME:** Press **Menu**, then the Up/Down buttons to access the Set Time line.

Press **OK** to select the field to be modified. A blue line will appear under the numbers.

Use the Up/down buttons to adjust the number

Use the L/R arrows to scroll to numbers to change

Press **OK** to save the setting, Press **Menu** to exit settings

**2. SET DATE:** Press **Menu**, then the Up/Down buttons to access the Set Date line.

Press **OK** to select the field to be modified. A blue line will appear under the numbers

Use the Up/down buttons to adjust the number

Use the L/R arrows to scroll to other numbers to change

Press **OK** to save the setting, Press **Menu** to exit settings

**3. TIME MODE:** 12 or 24 hours

Press **Menu** and then press the Up/Down buttons to access the Time Mode line.

Use the L/R arrows to scroll across to preferred Time Mode.

Press **Menu** to save the setting

**4. DATE MODE:** Day/Month/Year or Month/Day/Year

Press **Menu** and then press the Up/Down buttons to access the Date Mode line.

Use the L/R arrows to scroll across to preferred Date Mode.

Press **Menu** to save the setting

**5. LANGUAGE:** English, French, German, Dutch, Italian, Polish or Spanish

Press **Menu** and then press the Up/Down buttons to access the Language line.

Use the L/R arrows to scroll across to preferred Language

Press **Menu** to save the setting